

Kiehl-Legnodur-Titan

Satin-matt 2-component permanent coating

- ▲ Varnish-like drying, plasticiser-free polyurethane emulsion polish
- ▲ Coat thickness up to 25 µm
- ▲ High chemical resistance, e.g. against hand disinfectants
- ▲ Outstanding film-forming properties
- ▲ Hard-wearing, easy to clean protective film
- ▲ Maintenance of the coating after dry cleaning
- ▲ The film cannot be removed by wet stripping



Area of application

On real wood surfaces, which have been coated with wood oils or sealants. Also suitable for resilient floor surfaces and screed flooring which can be coated.

Application

Please test on a small inconspicuous spot before first application. The surfaces must be clean, release-agent free and properly prepared to ensure faultless adhesion and appearance. Before application, Kiehl-Legnodur-Titan (1st component) must be mixed with the second component Kiehl-Durator. Shake immediately. Allow to rest for 5 minutes. The resulting 2-component coating can be used for 6 hours. Close canister immediately after use. Avoid draughts during use and drying.

Preparation of the surface:

Dry clean parquet surfaces before coating (use Kiehl-Woodmaster-Pad-Fine). Resilient floor coverings must be stripped (Veroclean, 3 L to 8 L of water). Resilient floorings already coated with Kiehl-Legnodur must be dry cleaned using a Kiehl-Woodmaster-Pad-Fine. Accruing dust must be removed.

Coating:

Depending on the absorbency of the surface, 2–3 layers at intervals of approx. 90 minutes.

After preparing the surfaces, apply a thin coat of undiluted product to the clean floor using a flat mop or waxer. If necessary, carry out intermediate sanding using a Kiehl-Woodmaster-Pad-Fine after applying the first layer. Consumption: 30.0 ml/m² per application.



Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only! Protect from frost.

Ingredients

Synthetic dispersions, free from metal salts, polyethylene waxes, water-soluble solvents, preservatives.
pH value (concentrate): approx. 8

Art. No.	Packaging unit (PU)	Numbers of PU per pallet
j2213115	Carton of 5 L PCR canister + 100 ml Kiehl-Durator	112