

ARCANDIS-Classic

Concentrated dishwashing liquid, mildly chlorinated

- Liquid dishwasher concentrate for commercial single-tank and multi-tank dishwashers
- Fast and thorough removal of stubborn food residue, as well as tea and coffee remnants
- Very effective for all water hardness levels
- Prevents the formation of limescale deposits
- ▲ Ensures the hygienic cleanliness of the dishes





Area of application

For all types of alkali-resistant items made of porcelain, glass, stainless steel and plastic. Do not use to clean aluminium, rubber and items with sensitive decorations.

Application

Please test on a small inconspicuous spot before first application. Consult the manufacturer's instruction manual.

Mechanical dish washing:

The dosage values lie between 2-5 g/L of water.

Dosage takes place using the machine's integrated dosage mechanism or with the programmable KIEHL dosage devices. In order to achieve the best possible cleaning result, the dosage is set by a KIEHL service technician based on specific conditions (water hardness, level of soiling, type of machine). Consumption: no indication possible. Consumption depends on the specific conditions and specifications.

Ensure an optimum cleaning result by combining with the rinse aids ARCANDIS-Shine or ARCANDIS-Splend. When replacing the product, the dosage device and attached tubes must be thoroughly rinsed with water.





Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only!

Ingredients (according to 648/2004/EC)

Phosphonates < 5%, phosphates 15–30%, chlorine-based bleaching agents < 5%, alkalis, corrosion protection. pH value (concentrate): > 13.5 pH value (ready-to-use solution): approx. 11

Classification

Classification (in concentrate): GHS05, Danger. H314 Causes severe skin burns and eye damage. P280 Wear protective gloves/protective clothing/eye protection/face protection. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P308+P313 IF exposed or concerned: Get medical advice/attention. EUH031 Contact with acids liberates toxic gas. Contains: Sodium Hypochlorite / Potassium Hydroxide (INCI)

Art. No.	Packaging unit (PU)	Contents in kg	Numbers of PU per pallet
j560810	10 L canister	13.8	60
j560821	20 L canister	27.6	36
j560872	200 L drum	276	2

30.10.2021 Page 1 of 1